



MAINTENANCE

Periodic maintenance is required to ensure that your EcoSphere operates properly. The unit will display a PERFORM CLEANING reminder that is backlit in blue and flashes on and off, when it is time to perform regular maintenance.

If you are operating your unit in a severely polluted environment, cleaning of the unit, ActivePure® cell, and Filter Assembly should be done more frequently.

For optimal performance, and to prevent damage not covered by your warranty, install the optional EcoSphere Harsh Environment Prefilter.

Failure to perform routine maintenance could adversely affect the proper function of the unit or cause it to fail prematurely.

Refer to the Recommended Maintenance Schedule (other side) for frequency and types of maintenance to be performed.

See your Owner's Manual for maintenance procedures and details at aerushealthdirect.com.

To order replacement parts, contact Customer Service at 1-888-764-0693 or email support@aerusonline.com for additional support.



MAINTENANCE

These procedures should be performed according to the schedule below. For optimal performance, ActivePure® cells should be replaced as shown on the schedule below, even if the UV bulb appears to be working, or if the UV bulb fails to light. See your Owner's Manual for proper removal and installation instructions at aerushealthdirect.com.

	Every Month	Every Year	Every 2 Years	Notes
Vacuum Front & Rear Grill	•			
Vacuum ActivePure® Cell(s)	•			
Vacuum Filter Assembly	•			
Replace Optional Harsh Environment Prefilter	•			Replace with item 49911
Wash Filter Assembly		•		Or more often as needed
Replace ActivePure® Cells		1	2	US71090 Standard Ozone-Free ActivePure® Cell

1 ActivePure® Cells should be replaced every year if continuously used.

2 ActivePure® Cells should be replaced every two years if used less than 12 hours/day.